



Effortless precision cooking

Meet your new sous chef, the 900 SensePro® Induction Hob. A wireless food sensor measures the core temperature and communicates this with the hob so you can boil, fry, simmer and even sous vide with confidence. For restaurant-quality results, every time.

Product Benefits & Features



Enjoy precise results with the Food Sensor

Our wireless Food Sensor helps you create professional results, at home. The food sensor measures temperatures to the exact degree and communicates with the hob for precise results. Maintaining specific temperatures means you can even sous-vide on the hob.

- Hob type: Induction
- Hob with bevelled frame
- InfiSight™ controls with colour display
- Controls position: Front Right
- Illuminated controls
- Digital indications for each zone
- Induction zones with power booster function
- Pot detection
- Left front zone: Induction, 2300/3200W/210mm
- Left rear zone: Induction, 2300/3200W/210mm
- Middle front zone: No, 0W/0mm
- Middle rear zone: No, 0W/0mm
- Right front zone: Induction, 1400/2500W/145mm
- Right rear zone: Induction, 1800/2800W/180mm
- Key-lock function
- Child safety lock function
- Acoustic signal with switch off option
- CountUp Timer
- EcoTimer™
- Timer function
- CleverHeat™ function
- Easy installation thanks to snap-in system
- Main colour: Dark Grey



Control your hob with an intuitive touchscreen

Enjoy an intuitive experience with our full colour touchscreen. Select the food you want to cook and the hob displays live feedback for each zone, so you can effortlessly monitor the cooking process. It even gives you step-by-step instructions, for excellent results every time.



Merge zones for more room to cook with the Bridge function

The Bridge function lets you combine two separate cooking zones to create a single large surface. With the temperature and time settings automatically aligned, it's ideal for making the most of planchas or roasting pots.

Hob2Hood® for pure convenience

The Hob2Hood® function wirelessly connects your hob to your hood. Start cooking and the hood will automatically adjust the settings, providing the best extraction based on the power selected on the hob. It does the hard work so you can keep your mind – and your hands – on your cooking.

Every zone individually timed

Cooking multiple dishes can be complex, but setting timers shouldn't be. Set individual timers for each cooking zone, and when the timer's finished the hob automatically shuts off. It's smart assistance so every meal comes together with ease.

Product Specification

Product Installation	Built_In	Depth mm	520
Product Typology	Electric_Hob	Built in height mm	44
Product Classification	Performance	Width cutting	560
Installation	Independent	Depth cutting	490
Size	60	Radius cutting	5
Hob type	Induction Full	Fastening	Snap in System
Design family	Electrolux 100	Gas original	No
Main colour	Dark Grey	Gas replacement 2	No
Control Panel material	Glass	Gas replacement 3	No
Frame type	Bevelled 1 Side	Gas category	No
Frame material	No	Frequency	50-60
Knobs colour	No	Voltage	220-240V/400V2N
Top Control Place	Front Right		
Type of controls	Electronic, Parrot TFT		
Control function	3 step residual heat, Acoustic signal, Booster, Child-lock, Count up timer, Eco timer, Hob-hood connection, Key-lock function, Left Bridge, Melting, Minute minder, Pause, SenseCook Fry, SenseCook Pro, Sound off, Timer		
Other comments design	9-step regulation, 4-Booster		
Other comments categorisation	ref. 949 596 938, Flame Retardant Project		
Width mm	590		

