



Electrolux

ultraone™

CONSUMABLES & ACCESSORIES

 www.electrolux.com/shop



Silent Parketto
Ref: ZE115
Part nr: 9001677922



Turbo Brush
Ref: ZE119
Part nr: 9001678003



Delicate Care
Ref: KIT11
Part nr: 9001679597



Clean & Tidy
Ref: KIT12
Part nr: 9001679605



Animal Care
Ref: KIT13
Part nr: 9001679613



Performance Kit
Ref: SRK15
Part nr: 9001688903



s-bag® Ultra Long Performance
Ref: E210S
Part nr: 9001684613
s-bag® Anti-allergy
Ref: E206S
Part nr: 9001684605
s-bag® Anti-odour
Ref: E203S
Part nr: 9001684597
s-bag® Classic Long Performance
Ref: E201S
Part nr: 9001684589



Hygiene Washable
Ref: EFH12W
Part nr: 9001951194
Allergy Plus Washable
Ref: EFS1W
Part nr: 9001677682



Crispy Bamboo
Ref: ESBA
Part nr: 9001677773
Brown Sugar & Fig
Ref: ESFI
Part nr: 9001677781
Tropical Breeze
Ref: ESCO
Part nr: 9001677799
Citrus Burst
Ref: ESMA
Part nr: 9001677807
Evening Rose
Ref: ESRO
Part nr: 9001677765

 supportemea.electrolux.com

 www.electrolux.com

B11450202

